

Double-wall transport anchor



Installation and Application Instruction

Our products from the division BUILDING SOLUTIONS

SERVICES





- » On-site tests -> we ensure that your requirements are properly covered by our planning.
- » Test reports -> for your safety and documentation.
- » Trainings -> the knowledge of your employees from planning and production is enhanced by our experts on site, online or via webinar.
- » Planning support -> latest design software, planning documents, CAD data and much more can be downloaded any time from www.philipp-group.de.

HIGH DEMANDS ON PRODUCT SAFETY AND PRACTICALITY

- » Close cooperation with notified bodies and - if necessary - approval of our solutions.

TECHNICAL DEPARTMENT

- » Our expert-team will support you at any time during your planning phase with detailed advice.





CONTENT

GENERAL PRODUCT INFORMATION	Page	4
Material	Page	4
Marking	Page	4
INSTALLATION CONDITIONS	Page	5
Centre and edge distances	Page	5
Layer thicknesses	Page	5
Reinforcement	Page	5
BEARING CAPACITIES / WEIGHT OF ELEMENTS	Page	6
Bearing capacities / Concrete strength	Page	6
Maximum element weights	Page	6
INSTALLATION	Page	7
Calculation of the required anchor sizes	Page	7
Installation of Double-wall transport anchors	Page	7

PHILIPP Double-wall transport anchor

GENERAL PRODUCT INFORMATION



Double-wall transport anchors are part of the PHILIPP Transport anchor system and meet the needs of the German employer's liability insurance association for the building industry (BG BAU). The use of Double-wall transport anchors requires the compliance with this Installation and Application Instruction as well as the General Installation and Application Instruction. Double-wall transport anchors are designed for the transport (axial and lateral tension) as well as the tilt-up (lateral tension) of concrete panels.

Diagonal tension is limited to $\leq 30^\circ$ (picture 5). The crane hook or hook of the sling rope can be used as lifting device. This must be attached directly to the bended part at the top of the anchor. A rigging at the crossbar of the anchor (strut) is not allowed.

The user is personally responsible for further transmission of load into the concrete unit.

TABLE 1: DIMENSIONS

Ref. no.	Type	Design	Dimensions				
			L (mm)	b (mm)	$\varnothing d_{s,L}$ (mm)	$\varnothing d_{s,Q}$ (mm)	c (mm)
58HW27120600-1	● HW 2.7	A	600	120	14	14	88
58HW27130600-1	● HW 2.7	A	600	130	14	14	93
58HW27140600-1	● HW 2.7	A	600	140	14	14	98
58HW27150600-1	● HW 2.7	A	600	150	14	14	108
58HW27160600-1	● HW 2.7	A	600	160	14	14	108
58HW27170600-1	● HW 2.7	B	600	170	14	14	113
58HW27180600-1	● HW 2.7	B	600	180	14	14	118
58HW27190600-1	● HW 2.7	B	600	190	14	14	123
58HW27200600-1	● HW 2.7	B	600	200	14	14	128
58HW27210600-1	● HW 2.7	B	600	210	14	14	133
58HW27220600-1	● HW 2.7	B	600	220	14	14	138
58HW27230600-1	● HW 2.7	B	600	230	14	14	143


MATERIALS

The Double-wall transport anchor consists of a bended reinforcement bar B500B with a welded crossbar B500B as strut. Its diameter is $\varnothing 14$ mm of the longitudinal reinforcement bar ($\varnothing d_{s,L}$) as well as the crossbar ($\varnothing d_{s,Q}$).


In order to simplify the installation both ends of the anchor are bended in 135° (picture 1).

MARKING

All Double-wall transport anchors have a coloured tag in order to show the bearing capacity. This tag must be still visible after concreting the two layers of the double wall.



INSTALLATION CONDITIONS



CENTRE AND EDGE DISTANCES

Picture 4 shows the minimal edge and centre distances. Edge distances given in table 2 are also valid as distances to openings (e.g. windows) in the panel.




TABLE 2: EDGE AND CENTRE DISTANCE


Edge distance a_r (mm)	Centre distance a_a (mm)
≥ 400	≥ 600

LAYER THICKNESSES

The position and installation of Double-wall transport anchors in precast concrete units require minimum layer dimensions for a safe load transfer. Depending on the concrete cover to the inner and outer face of the double wall the thickness of each layer must be chosen according to table 3.

TABLE 3: LAYER THICKNESSES


Minimum layer thickness (mm)	Nominal cover (outer face) $c_{v,a} / c_{v,i}$ (mm)	Concrete cover (inner face) c_a / c_i (mm)
50	20	> 10
60	30	
65	40	
75	50	



Picture 6 Layer thicknesses

REINFORCEMENT

When using Double-wall transport anchors the outer and inner layer of the double wall must be reinforced with a minimum reinforcement $\varnothing 8$ mm / 200 mm ($d_{s,h,a} / d_{s,h,i} / d_{s,v,a} / d_{s,v,i}$) cross-wise. Furthermore both layers must be connected to each other with lattice girders (acc. to a national technical approval or ETA). The maximum distance between the lattice girders does not exceed 625 mm.



Picture 7 Reinforcement

PHILIPP Double-wall transport anchor

BEARING CAPACITIES / WEIGHT OF ELEMENTS

At the first time of lifting both layers of the double wall must have a minimum concrete strength according to table 4. With this concrete strength the bearing capacity for axial and diagonal tension ($\leq 30^\circ$) is 2700 kg. For lateral tension the Double-wall transport anchors have half of the axial bearing capacity with a concrete strength f_{cc} of 19 N/mm². However, this is not a limitation as during tilt-up only half of the weight has to be lifted (please refer to the General Installation and Application Instruction).

TABLE 4: BEARING CAPACITIES

Axial tension / diagonal tension perm. F_z $\beta_{\max} 30^\circ / \gamma_{\max} 15^\circ$ (kN)	Perm. F	
	if $f_{cc} 15 \text{ N/mm}^2$ Lateral tension perm. F_Q $\gamma_{\max} 90^\circ / \beta_{\max} 30^\circ$ (kN)	if $f_{cc} 19 \text{ N/mm}^2$ Lateral tension perm. F_Q $\gamma_{\max} 90^\circ / \beta_{\max} 30^\circ$ (kN)
27.0	11.7	13.5

The weight of 1.0 t corresponds to 10.0 kN.

TABLE 5: MAXIMUM WEIGHT OF ELEMENTS



	Load case (mould adhesion not considered)	2 load bearing anchors symmetric to centre of gravity		4 load bearing anchors symmetric to centre of gravity with compensation rig			
		Max. element weight G ① if f_{cc} 15 N/mm ² (t)	if f_{cc} 19 N/mm ² (t)	Max. element weight G ① if f_{cc} 15 N/mm ² (t)	if f_{cc} 19 N/mm ² (t)		
Tilt-up	Lateral tension ② ($\gamma = 90^\circ, \beta = 0^\circ$, cross beam required)		3.60	4.15		7.20	8.30
	Diagonal/lateral tension ② ($\gamma = 90^\circ, \beta = 15^\circ$)		3.48	4.01		6.96	8.02
	Diagonal/lateral tension ② ($\gamma = 90^\circ, \beta = 30^\circ$)		3.11	3.60		6.22	7.20
Transport	Axial tension ($\beta = 0^\circ$, cross beam required) with tilt-up table		4.15	4.15		8.30	8.30
	Diagonal tension ($\beta = 15^\circ$)		4.01	4.01		8.02	8.02
	Diagonal tension ($\beta = 30^\circ$)		3.60	3.60		7.20	7.20
	Lateral tension ② ($\gamma = 90^\circ, \beta = 0^\circ$, cross beam required)		1.80	2.07		3.60	4.15
	Diagonal/lateral tension ② ($\gamma = 90^\circ, \beta = 15^\circ$)		1.74	2.00		3.48	4.01
	Diagonal/lateral tension ② ($\gamma = 90^\circ, \beta = 30^\circ$)		1.55	1.80		3.11	3.60

① The given element weights G are valid for a dynamic (hoisting) coefficient of 1.3 (in accordance with EN 13155 and VDI/BV-BS 6205).

② For lateral tension a steel angle (S235 / min. 50x50x6 / L = 250 mm) must be installed as a corner guard (to protect the edge of the layer). The angle must be secured against falling down.




INSTALLATION

CALCULATION OF THE REQUIRED ANCHOR SIZES (COMMON FORMULA: ANCHOR WIDTH b = HEIGHT OF LATTICE GIRDER H_{GT})



INSTALLATION OF DOUBLE-WALL TRANSPORT ANCHORS

The Double-wall transport anchor must be installed flush to the top edge of the wall. For concreting the anchor must be fixed to its position. This can be done by connecting it to the lower transverse reinforcement or an additional mounting rebar.



CONCRETE COVER

After vibrating of the layers a visual inspection is required. If the minimum concrete cover on the inner side of the layer is not reached, the concrete cover in the anchor area must be increased accordingly.



**PHILIPP GmbH
Headquarters**

Lilienthalstraße 7-9
63741 Aschaffenburg

+49 6021 40 27-0

info@philipp-gruppe.de

**PHILIPP GmbH
Production and logistics**

Hauptstraße 204
63814 Mainaschaff

+49 6021 40 27-0

info@philipp-gruppe.de

**PHILIPP GmbH
Office Coswig**

Roßlauer Straße 70
06869 Coswig/Anhalt

+49 34903 6 94-0

info@philipp-gruppe.de

**PHILIPP GmbH
Office Neuss**

Sperberweg 37
41468 Neuss

+49 2131 3 59 18-0

info@philipp-gruppe.de



PHILIPP Vertriebs GmbH

Pfaffing 36
5760 Saalfelden / Salzburg

+43 6582 7 04 01

info@philipp-gruppe.at



Visit us!

www.philipp-group.de